



RIVETEC s.r.o.

U Vodárny 1506 / 1 B22  
397 01 Písek

Tel.: +420 382 206 711  
Fax: +420 382 206 719  
E-Mail: [info@rivetec.cz](mailto:info@rivetec.cz)  
Web: [www.rivetec.cz](http://www.rivetec.cz)



GEBR. TITGEMEYER GmbH & Co. KG

Hannoversche Straße 97  
49084 Osnabrück

Tel. +49 541 5822-0  
Fax +49 541 5822-491

E-Mail: [vertrieb-gfb@titgemeyer.com](mailto:vertrieb-gfb@titgemeyer.com)  
Web: [www.titgemeyer.com](http://www.titgemeyer.com)



## Riveting Tool RL 40N/i RL 60N/i/iHV Operating Manual



## Table of contents

<b>Guiding instructions</b> .....	<b>4</b>
Cautions, instructions and procedural sections in the operating instructions .....	5
Markings on the riveting tool .....	6
<b>Safety instructions</b> .....	<b>7</b>
Basic requirements while dealing with the riveting tool .....	8
Noise and vibration levels of the RL 40N / RL 60N.....	10
<b>Description of the riveting tool</b> .....	<b>11</b>
<b>Necessary tools</b> .....	<b>13</b>
<b>Storing the riveting tool</b> .....	<b>13</b>
<b>Preparing the riveting tool</b> .....	<b>14</b>
<b>Operating the riveting tool</b> .....	<b>17</b>
Setting the blind rivet .....	18
Changing the nose piece .....	19

# RIVETEC

TITGEMEYER Group



1 / 1

## ES PROHLÁŠENÍ O SHODĚ EU DECLARATION OF CONFORMITY

Název produktu:  
Product Name: **RL 60N/i/iHV**

Kat. číslo:  
Cat. Number: **99 - 0023N/i/iHV**

Určení produktu:  
Specifications: pneumaticko-hydraulické nýťovací nářadí pro usazování maticových nýtů  
air-hydraulic riveting tool for installing threaded rivets

Výrobce

Manufacturer

RIVETEC s.r.o.  
U Vodárny 1506 / 1 B22  
CZ – 397 01 Písek  
IC 60647761

prohlašuje, že uvedený výrobek byl vyroben  
v souladu s požadavky následujících směrnic:

declares that the product was manufactured  
in conformity with the requirements of the following  
EC Directive:

ČSN EN ISO 12100 Bezpečnost strojních zařízení  
ČSN EN 349 Bezpečnost strojních zařízení – Nejmenší mezery k zamezení stlačení částí lidského těla  
ČSN EN 963 Bezpečnost strojních zařízení – Ochranné kryty  
ČSN CR 954-100 Bezpečnost strojních zařízení: části řídicích systémů  
ČSN EN 983 Bezpečnost strojních zařízení – Bezpečnostní požadavky pro fluidní zařízení a jejich součásti – Pneumatika  
ČSN EN 999 Bezpečnost strojních zařízení – Umístění ochranných zařízení s ohledem na rychlosti přiblížení částí lidského těla  
ČSN EN 61000-6-1 ed. 2 Elektromagnetická kompatibilita – Odolnost  
ČSN EN 61000-6-4 ed. 2 Elektromagnetická kompatibilita – Emise  
ČSN EN 60204-1 Bezpečnost strojních zařízení – Elektrické zařízení strojů – Všeobecné požadavky  
ČSN EN ISO 13850 Bezpečnost strojních zařízení – Nouzové zastavení – Zásady pro konstrukci  
ČSN EN ISO 13857 Bezpečnost strojních zařízení – Bezpečné vzdálenosti k zamezení úsahu k nebezpečným místům horními a dolními končetinami  
ČSN EN ISO 1037 Bezpečnost strojních zařízení – Zamezení neočekávanému spuštění  
ČSN EN 614-1 Bezpečnost strojních zařízení – Ergonomické zásady navrhování – Část 1  
ČSN EN 60430-1 ed. 2 Rozvaděče nn – Část 1  
2006/95/ES Elektrická zařízení určená pro používání v určitých mezích napětí  
2004/108/ES Elektromagnetická kompatibilita  
2006/42/ES Směrnice o strojích a zařízeních  
Zákon č. 22/1997 Sb. o technických požadavcích  
Zákon č. 71/2000 Sb. (změna zákona č. 22/1997 Sb.)  
Zákon č. 205/2002 Sb. (změna zákona č. 22/1997 Sb.)  
Zákon č. 226/2003 Sb. (změna zákona č. 22/1997 Sb.)  
Zákon č. 102/2001 Sb. o obecné bezpečnosti výrobků  
Zákon č. 227/2003 Sb. (změna zákona č. 102/2001 Sb.)  
Nařízení vlády č. 18/2003 Sb. o požadavcích na výrobky z hlediska jejich elektrické kompatibility  
Nařízení vlády č. 204/2003 Sb. o technických požadavcích na stroje a zařízení

Místo a datum:  
Place and date:

Písek  
27.11.2016

Jméno, funkce a podpis autorizované osoby:  
Name, Title and Signature of Authorized Person:

Ing. Antonín Solfronk  
Managing Director

**ES PROHLÁŠENÍ O SHODĚ  
EU DECLARATION OF CONFORMITY**

Název produktu:  
Product Name: **RL 40N/i**  
Kat. číslo:  
Cat. Number: **99 - 0022N/i**

Určení produktu:  
Specifications: pneumaticko-hydraulické nýťovací nářadí pro usazování matcových nýtů  
air-hydraulic riveting tool for installing threaded rivets

Výrobce  
Manufacturer: RIVETEC s.r.o.  
U Vodárny 1506/1 B22  
CZ – 397 01 Písek  
IČ: 60647761

**prohlašuje, že uvedený výrobek byl vyroben  
v souladu s požadavky následujících směrnic:** **declares that the product was manufactured  
in conformity with the requirements of the following  
EC Directive:**

ČSN EN ISO 12100 Bezpečnost strojních zařízení – Nejmenší mezery k zamezení sřláčených částí lidského těla  
ČSN EN 348 Bezpečnost strojních zařízení – Ochranné kryty  
ČSN EN 953 Bezpečnost strojních zařízení – Ochranné kryty  
ČSN CR 954-100 Bezpečnost strojních zařízení – Části řídicích systémů  
ČSN EN 983 Bezpečnost strojních zařízení – Bezpečnostní požadavky pro fluidní zařízení a jejich součásti – Pneumatika  
ČSN EN 989 Bezpečnost strojních zařízení – Umístění ochranných zařízení s ohledem na rychlost přiblížení částí lidského těla  
ČSN EN 61000-6-1 ed. 2 Elektromagnetická kompatibilita – Odolnost  
ČSN EN 61000-6-4 ed. 2 Elektromagnetická kompatibilita – Emise  
ČSN EN 60204-1 Bezpečnost strojních zařízení – Elektrické zařízení strojů – Všeobecné požadavky  
ČSN EN ISO 13850 Bezpečnost strojních zařízení – Nouzové zastavení – Zásady pro konstrukci  
ČSN EN ISO 13857 Bezpečnost strojních zařízení – Bezpečné vzdálenosti k zamezení úsohu k nebezpečným místům horními a dohřními končetinami  
ČSN EN ISO 1037 Bezpečnost strojních zařízení – Zamezení neočekávanému spuštění  
ČSN EN 614-1 Bezpečnost strojních zařízení – Ergonomické zásady navrhování – Část 1  
ČSN EN 60439-1 ed. 2 Rozvaděče nn – Část 1  
2006/95/ES Elektrická zařízení určená pro používání v určitých mezích napětí  
2004/108/ES Elektromagnetická kompatibilita  
2006/42/ES Směrnice o strojích a zařízeních

Zákon č. 221/1997 Sb. o technických požadavcích  
Zákon č. 71/2000 Sb. (změna zákona č. 221/1997 Sb.)  
Zákon č. 205/2002 Sb. (změna zákona č. 221/1997 Sb.)  
Zákon č. 226/2003 Sb. (změna zákona č. 221/1997 Sb.)  
Zákon č. 102/2001 Sb. o obecně bezpečnosti výrobků  
Zákon č. 227/2003 Sb. (změna zákona č. 102/2001 Sb.)  
Nařízení vlády č. 18/2003 Sb. o požadavcích na výrobky z hlediska jejich elektrické kompatibility  
Nařízení vlády č. 204/2003 Sb. o technických požadavcích na strojní zařízení

Místo a datum:  
Place and date: Písek  
27. 11. 2016

Jméno, funkce a podpis autorizované osoby:  
Name, Title and Signature of Authorized Person: Ing. Antonín Šolfronk  
Managing Director

<b>Maintaining the riveting tool.....</b>	<b>20</b>
Bleeding the hydraulic section, refilling hydraulic oil .....	20
Changing the jaws .....	22
Adjusting the jaw case body .....	24
Table for torque values .....	25
<b>Servicing and cleaning the riveting tool .....</b>	<b>26</b>
<b>Maintenance intervals .....</b>	<b>27</b>
<b>Trouble shooting.....</b>	<b>28</b>
<b>Disposal of the riveting tool .....</b>	<b>31</b>
<b>Technical data .....</b>	<b>31</b>
<b>Guarantee, Package Contents .....</b>	<b>33</b>
<b>Declaration of conformity .....</b>	<b>34</b>

## Guiding instructions

<b>Instruction</b>	The legislator prescribes that the user must be well trained for using compressor-driven riveting tools. On request, this training could be done by dealer or directly by RIVETEC s.r.o.
<b>Technological level</b>	This riveting tool is as per the latest technological standards. For the device to function properly, it is necessary to operate it in an expertly manner, with adherence to safety requirements.
<b>Reading the guiding instructions</b>	Before using the riveting tool for the first time, read the guiding instructions carefully.
<b>Procedures</b>	All the procedures necessary for the operation have been described in these guiding instructions. You may carry out only those procedures, which have been described here.
<b>Obstructions</b>	In case of obstructions, you may repair only those obstructions, which have been marked with an O (Operator).
<b>Illustrations and position-codes</b>	All the illustrations and position-codes in the individual diagrams take reference from the list of parts in the last pages.
<b>Table for torque values</b>	For sizes of screws and threads you will find a table containing the torque values on page 25 of the chapter "Maintening the riveting tool".

## Guarantee

Other than the official guarantee (6 months), the company RIVETEC also offers a guarantee of an additional 6 months from the date of purchase. (The bill being the proof thereof).

The following working parts are excluded from the guarantee agreement:

- Nose piece (1)
- Spent mandrel collector (6)
- Socket head screw (7) with O-ring (8)
- O-rings (5) and (19)
- Jaw case (14)
- Jaws (15)

## Package Contents

- 1x Riveting Tool RL 40N/i / RL 60N/i/iHV
- 1x Swivel Joint
- 1x Oil Gun
- 1x Adapter Screw
- 1x Box Wrench SW11
- 1x Internal Hex Key SW4
- 1x Wrench SW11
- 1x Nose Piece Ø4 (is located in the bottom of the riveting tool)
- 1x Nose Piece Ø5 (is located in the bottom of the riveting tool)
- 1x Nose Piece Ø6 (is located in the bottom of the riveting tool)
- 1x Noce Piece Ø6,4 (mounted on the nose cap of the riveting tool)

List of spare parts are available upon request from your dealer.

## Disposing of the riveting tool

Ensure that the hydraulic oil is inside the riveting tool. Dispose it off in an environmentally friendly manner. Send the riveting tool back to the manufacturer in it's original packing, if still available.


## Technical data

Type of riveting tool:	RL 60N/i/iHV
Height:	340 mm <sup>1</sup>
Width:	328 mm <sup>1</sup>
Weight:	2,6,6kg <sup>1</sup>
Operating pressure:	5-7 bar
Compressed air supply	
Nominal diameter:	DN 6
Power output (at 6 bar):	ca. 18,2 kN
Operating stroke:	ca. 26 mm
Operating range:	Blind rivet-shaft Diameter 4.0 to 6.4 mm

Sound emission level in the workplace:	$L_{PAI} < 70 \text{ dB(A)}$
Vibration level:	$a_{hw} < 2,5 \text{ m/s}^2$

If desired, the nose cap (2) can also be counted in other measurements.

<sup>1</sup> The length and height and weight measurements of the riveting tool are as per the standard procedures.



## Cautions, instructions and procedural sections in the operating instructions

Please follow the instructions and safety informations.

In these operating instructions, some sections have been further illustrated through diagrams  
Please acquaint yourself well with these diagrams and their meanings:



**Caution** Hazard of injury! This marking indicates a potential hazard.



**Attention** Material damage! This marking points at a procedure, which may cause damage to the riveting tool or the work-piece.



**Note** This marking indicates useful information.

- This point (•) marks every paragraph, which requires you to act by yourself.




**Attention** Environmental hazard! This marking indicates a potential environmental hazard.

### Markings on the riveting tool



This pictogram indicates that you must read the operating instructions before using the riveting tool.



- A Marking of the type
- B Serial number
- C CE-marking
- D Instruction for reading the operating instructions
- E Name of the manufacturer as well as the value of the maximum operating pressure
- G Supplier RIVETEC

### Disposing of the riveting tool

Ensure that the hydraulic oil is inside the riveting tool. Dispose it off in an environmentally friendly manner. Send the riveting tool back to the manufacturer in it's original packing, if still available.


### Technical data

Type of riveting tool:	RL 40N/i
Height:	283mm <sup>1</sup>
Width:	317mm <sup>1</sup>
Weight:	2,0 kg <sup>1</sup>
Operating pressure:	5-7 bar
Compressed air supply	
Nominal diameter:	DN 6
Power output (at 6 bar):	ca. 14,7kN
Operating stroke:	ca. 14mm
Operating range:	Blind rivet-shaft Diameter 4.0 to 6.4 mm

Sound emission level in the workplace:	L <sub>PAI</sub> < 70dB(A)
Vibration level:	a <sub>hw</sub> < 2,5m/s <sup>2</sup>

If desired, the nose cap (2) can also be counted in other measurements.

<sup>1</sup> The length and height and weight measurements of the riveting tool are as per the standard procedures.



## Trouble shooting

Problems	Cause	Solution
Mandrel is not sucked	Supply of compressed air is too rare  X-value is too low Safety valve gets blown off Safety valve is not tight Safety valve is defective O-ring (19) is defect	(O) Check supply of compressed air (O) Set the compressed air setting on the maintenance unit at 6 bar (P) If operating pressure is OK, deliver riveting tool from overhaul (O) Reset the value of X (see “Adjusting the jaw case body”) (O) Check the setting of compressed air (O) Tighten the safety valve (O) Replace safety valve (P) Insert new O-ring
Air bubbles in the hydraulic system	Oil level is too low Not bled correctly  O-ring is leaking	(O) Check oil level and fill up (O) Bleed the hydraulic unit (see page 20 “Maintaining the riveting tool”), change the O-ring if required (P) Deliver riveting tool from overhaul
Stroke is too short	Oil level is too low X-value is too low	(O) Check oil level and fill up (O) Reset the value of X (see page 24 “Adjusting the jaw case body”)
Loss of hydraulic oil due to leakage	Riveting tool is defective	(P) Deliver riveting tool from overhaul
Safety valve gets blown off	Compressed air pressure is too high Valve is defective	(O) Check and adjust compressed air setting (O) Replace safety valve
Excessive loss of oil from riveting tool	Leaking and worn out O-rings inside the riveting tool	(P) Withdraw the riveting tool from the work-routine, and order an overhaul

## Safety instructions

### Application as per the purpose

The riveting tool is meant exclusively for setting blind rivets. The riveting tool RL 40N/i / RL 60N/i/iHV has been designed for setting all materials of blind rivets with a shank diameter of 4.0 to 6.4 mm. This riveting tool must be used only as a hand-held device! The client is fully responsible for any modifications to the riveting tool!

### Improper use

Never throw away or drop the riveting tool!

### Clean and dry compressed air

Please take care that only clean and dry compressed air is let into the riveting tool. Moisture and dirt can damage the riveting tool. Use only such compressed air, which falls into class 2 of air quality as per ISO 8573-1.



**Caution** Hazard of injury because of explosion! Never use the riveting tool in an atmosphere prone to explosions. Ensure that the workplace is well lit and clean.  
Hazard of injury due to the openly moving compressed air hose. Connect and lay the compressed air hose properly.  
Hazard of injury due to tripping over! Lay the compressed air hose in such a way that nobody should trip over it.



**Attention** Material damage! The maximum operating pressure is 7 bar. For increasing the durability of the riveting tool, it is recommended to fit a compressed air-maintenance unit in the compressed air hose.

**Basic requirements while dealing with the riveting tool**



**Caution** Do not operate the riveting tool when it is directly pointing at any person.

Follow the prevalent guidelines for the prevention of accidents in the respective country.

Use only those fittings and hoses, which have been approved for the operating pressure.

Disconnect the compressed air supply from the riveting tool at the time of installation or maintenance.

Wear personal safety gear (safety glasses and safety helmet).



**Attention** Please pay attention to the information on the pack of the blind rivet.

Use the riveting tool only at operating temperatures above 5°C and 45°C.

For different diameters of the rivet shank, use the appropriate nose piece, as prescribed.

Do not throw away the riveting tool.

Problems	Cause	Solution
Blind rivet is set correctly	<p>Supply of compressed air is too rare</p> <p>Jaws are dirty Jaws are worn out</p> <p>Jaw case and jaw case body are loose</p> <p>Oil shortage/ no stroke</p>	<p>(O) Check compressed air supply</p> <p>(O) Set the compressed air setting on the maintenance unit at a maximum of 7 bar</p> <p>(O) Clean jaws</p> <p>(O) Change jaws (see page 20 “Maintaining the riveting tool”)</p> <p>(O) Tighten the screws/ nuts (see page 20 “Maintaining the riveting tool”)</p> <p>(O) Eliminate oil shortage</p>
Blind rivet can not be inserted	<p>Oil quantity in the system too high</p> <p>Wrong nose piece</p> <p>Nose piece is loose</p> <p>Travel-path of the mandrel is blocked</p> <p>X-value is too low</p>	<p>(O) Check and adapt oil quantity (see “Maintaining the riveting tool”)</p> <p>(O) Change nose piece (see page 17 “Operating the riveting tool”)</p> <p>(O) Tighten screws/ nuts (see page 20 “Maintaining the riveting tool”)</p> <p>(O) Empty riveting tool mandrel collector</p> <p>(O) Reset the value of X (see page 24 “Adjusting the jaw case body”)</p>
Air adjustment nozzle is stuck	The screw is too tight	(P) Change or clean O-ring



## Trouble shooting

Operations, which may be carried out by the operator, are marked with the letter **O**.

Operations, which may be carried out only by an expert person, are marked with the letter **P**.



**Caution** Hazard of accident! In any case, keep the compressed air supply detached till the source of the problem is eliminated.



**Attention** Material damage! Operations, which have been marked with the letter **P**, must be carried out only by well-trained experts. Deliver riveting tool from overhaul

Any replacement of original spare parts may be carried out only by well-trained experts.



**Note** After every instance of problem-removal, a thorough functional check must be carried out.

**Maintenance and servicing** The operator may only carry out the maintenance and repair work described in these operating instructions

**Service instructions** Maintenance and service work not described in these operating instructions may only be carried out by trained specialists following instruction by RIVETEC on the basis of the service instructions which also exist. See the address on last Page for more information on service instructions and training.



**Note** The manufacturer accepts no liability for damage resulting from incorrect repairs or the use of spare parts from other sources.

At the time of leaving the workplace, do not leave the riveting tool with pressure on.

**Guarantee** A guarantee is void, if any repair work carried out on the riveting tool has led to any damage of the riveting tool.

**Declaration of conformity** The riveting tool RL 40N/i / RL 60N/i/iHV has been checked and manufactured according to European guidelines. The declaration of conformity can be found on the second last page.

**GS-checked** In addition to this, the riveting tool has been checked by the TÜV Product Service GmbH, Hannover, and certified with a GS-mark.

**Noise and vibration levels of the RL 40N/i / RL 60N/i/iHV**

**Noise level**

The sound-emission level for workplaces is  $L_{pA1} < 70 \text{dB(A)}$  as per ISO 10843 and DIN EN 3744.

**Vibration level**

The effective value measured on acceleration with the handle, as per ISO/FDIS 8662-11, is  $a_{hw} < 2,5 \text{m/s}^2$ .

**Maintenance Intervals**

Interval	Activity	How?	Who?	Remark
Daily before use	Check for cracks	Visual check	Operator	—
Daily before use	Check nose piece for rivet diameter and wear and tear	Visual check	Operator	If required, replace nose piece
Daily before use	Check the jaws	Functional check	Operator	If required, clean and change jaws
Daily before use	Check for oil leaks from the riveting tool	Visual check, if required, fill with acid-free oil, and bleed hydraulic system	Operator	—
Daily after use	Clean riveting tool	With a rag	Operator	—
Daily after use	Oil moving parts not trigger (13)	With acid-free oil e.g. ELFOLNA 46	Operator	—
Either throughout the 3 years or after a period of 2000 working hours	Change hydraulic oil	With acid-free oil e.g. DEA Astron HLP 32	Professional	A complete oil change, to be carried out only by a professional




## Servicing and cleaning riveting tool

**Caution** Hazard of injury if handled in an improper manner! Servicing, maintenance and repairs of the riveting tools must be carried out professionally. On completing this work, there should not be any more hazard to the operator, if used as per the regulations. The operator may only carry out the operations mentioned here.  
Hazard of injury if the riveting tool falls down! The hydraulic housing must always be kept dry, clean and oil- and fat-free.



**Attention** Material damage due to corrosion! Do not use any highly active cleaning agents or combustible liquids for cleaning purpose!

The following routine is recommended:  
The riveting tool must be cleaned and checked for mechanical defects as per the respective application type.  
After the riveting tool has been cleaned and when it is to be stored for a long period, lightly grease all the external metallic components (see page 27 "Maintenance intervals").




## Description of the riveting tool

The riveting tool RL 40N/i / RL 60N/i/iHV works according to a pneumatic-hydraulic principle.


It consists of the following operation-related components:

1	Nose piece	Serves for the correct reception of the blind rivet – others are screwed in the bottom of the valve housing
2	Nose cap	Conceals the jaw case body and the jaw case
3	Hydraulic housing	The pneumatic and the hydraulic units are located in the hydraulic housing
4	Safety mechanism	Prevents the spent mandrel from leaving the tool
6	Spent mandrel collector	Serves the purpose of collecting spent mandrels



→ **Note** The socket head screw (7) and the O-ring (8) are screwed tightly into the grip. The socket head screw (7) must not be loosened, else the hydraulic oil will leak.

- 7 Socket head screw Locking for the hydraulic oil system
- 8 O-Ring Sealing of the hydraulic oil system
- 9 Safety valve (Brass) In case of very high pressures (approx. 8 bar or more), it opens, and lets the air out.
- 10 Plug Serves the purpose of protection of the thread and also against dirt
- 11 Swivel-joint Serves as the connection for compressed air hoses (operating pressure 6 bar)
- 12 Knurled nut Adjustment of the exhaustion performance
- 13 Trigger When activated, the riveting procedure starts
- 25 Hang-up eyelet For hanging up on a hook whenever stationary



**Table for torque values**

In the following table, you will find torque values, which you are required to adhere to while tightening the screws/ nuts.

Pos.	Name	Threading	Torque value MA in Nm
1	Nose piece	Metrical M10x1	5
7	Socket head	Metrical M6	4
9	Safety valve	Withworth-pipe-thread 1/4"	20
11	Swivel joint	Withworth-pipe-thread 1/4" Metrical	20
18	Jaw case body	Metrical M11x1	6
20	Lock nut	Metrical M11x1	6

### Adjusting the jaw case body




In order to enable the riveting tool to travel an adequate stroke, the gap between the jaw case (14) and hydraulic housing (3) must be adjusted correctly.

- Detach the compressed air supply.

**Caution** Hazard of injury by means of bruises or cuts in case of unchecked cutting stroke! Always detach compressed air supply before take off the nose cap (2).

**Attention** Material damage! Do not let O-ring (19) get damaged. If the O-ring has been damaged, replace immediately.

- Release and take off nose cap (2) with knurled ring (33)
- Check measure X between front part of jaws case (14) and front part of hydraulic body (check picture). For standard setting is value X = 91 mm.
- Release securing nut (20) with wrench key 17 mm from interposer (18) – wrench key 14 mm, until interposer (18) is rotating freely.
- Interposer (18) screw on or off in order to reach correct value of X measure
- Screw securing nut (20) against interposer (18).
- Hold interposer (18) with wrench key 14 mm in position and screw secure nut (20) by wrench key 17 mm. (see page 25 for correct torque in table).



### Necessary tools

You will require the following tools for all installation, servicing and maintenance work. The tools SW17, SW19, can be ordered.

#### Tools

- |                    |   |
|--------------------|---|
| — Internal hex key | SW4 (23)                                    |
| — Box wrench       | SW11 (24)                                   |
| — Wrench           | SW11, SW17 <sup>1</sup> , SW19 <sup>1</sup> |

<sup>1</sup> No delivery possibility

### Storing the riveting tool

#### Until first use


If you do not use the riveting tool immediately, store it inside the original packing, dry and dust-free.

#### Long term storage after usage

Clean the riveting tool (see page 26 “Servicing and cleaning the riveting tool”). Turn off the spent mandrel collector (6), unscrew the swivel joint (11), and close the opening with a plug (10). As far as possible, store all parts in their original packing.

#### After long-term storage

After long-term storage (about 3 years), change the hydraulic oil before re-use.



## Preparing the riveting tool

**Package insert**

The components ordered by you are marked as per the checklist found inside the packing.



**Note** Check whether the package contents is complete (page 33).

In every case, please carry out a visual check of the riveting tool before starting any work:

- for external damages,
- for oil leakage from the riveting tool.

- Remove the plug (10) from the connection port, and store in the original packing.




**Note** The swivel joint (11) and the safety valve (9) can be alternatively fitted on both the sides of the hydraulic housing. The diagram below shows the arrangement for a right-hander



**Note** In case of all screw-fittings, observe the table for torque values on page 25 of the chapter “Maintaining the riveting tool”

- Screw on the swivel joint (11) and tighten using the wrench SW17 (see page 25 “Table for torque values”).






**Attention** Material damage! If mounted correctly, then the jaws must jut out at the same level from the jaw case (14). It should be possible to press them into the jaw case (14) with the thumb.

**Note** At the time of replacing the jaws, it may be observed that the lock nut (20) at the jaw case body (18) loosens and adjusts itself. In such a case, the gap between X needs to be readjusted (see page 24 “Adjusting the jaw case body”).

- Check the distance X (see page 24 “Adjusting the jaw case body”).

- Install the nose cap (2).

## Maintaining the riveting tool



### Changing the jaws

The jaws are subject to mechanical wear out, and must be replaced as soon as they start losing grip over the mandrel.

- Detach the compressed air supply.


**Caution** Hazard of injury by means of bruises or cuts in case of unchecked cutting stroke! Always detach compressed air supply before take off the nose cap (2).

**Attention** Material damage! Do not let O-ring (19) get damaged. If the O-ring has been damaged, replace immediately.

- Release and take off nose cap (2) with knurled ring (33)
- By the typ i / iHV unscrew the front nozzle with the screw key Nr.19
- Release secure ring (34) and release jaws pusher (14) carefully off-screw by hand and take off 3 pieces of jaws (15) which are freely placed in jaws case (14)
- Take off Jaws guide (16) and spring (17)
- Old jaws (15) take off jaws case (14), grease slightly outside part of jaws and place them into jaws case correctly.
- Install guide (16) with spring (17) into jaws case (14)



## Preparing the riveting tool



**Note** Depending on the type of compressed air supply, it may be necessary to connect a fitting different from the one provided, to the riveting tool. For this, you need to have a fitting having a 1/4" Withworth pipe thread as per ISO 228.






**Attention** Material damage by compressed air!  
As per norm ISO 8573-1, class 2, compressed air must be dry and clean. We recommend that you fit a compressed air-maintenance unit to the riveting tool.

- Compressed air hose should be connected to the swivel joint (11), as prescribed.



**Note** The operating pressure must be between a minimum of 5 and a maximum of 7 bar!



- ➔ **Note** You may use nose pieces for rivet shank diameter of 4.0 to 6.4 mm
- ➔ **Note** Before you start the operation procedure, check whether the appropriate nose piece (1) has been fitted. If not, then the same should be replaced with the appropriate nose piece.


- Unscrew the right nose piece (1) from the locating hole on the underside of the riveting tool, using a box wrench SW11 (24).
- Unscrew the nose piece (1) from the nose cap (2), and screw into the locating hole.

- ➔ **Note** Clean the replaced nose piece (1) and screw into the locating hole on the underside of the riveting tool using the box wrench SW11 (24)



**Attention** Material damage due to damaged threads. It should be possible to screw on the nose piece with bare hands. Do not use force! You must overcome the spring thrust on the jaws.

- Screw the nose piece (1) carefully into the nose cap (2).
- Tighten the nose piece (1) using box wrench SW11 (24) (see page 25 "Table for torque values").
- Screw on the spent mandrel collector (6).




- Bend the riveting tool carefully towards the front at an angle, and fix e.g. inside a vice (like illustrated in the diagram).

This position is critical, where the trapped air can escape when necessary (bleeding the hydraulic section).

**Attention** Environmental hazard! Always use a large bowl for collecting oil. Please observe all the environmental regulations prevalent in the respective area.

**Attention** Material damage! Do not let the O-ring (8) be damaged. If the O-ring gets damaged, then replace immediately.

- Unscrew the socket head screw (7) in the hydraulic housing carefully, using the internal hex key SW4 (23).
- Screw the oil refill adapter screw (22) into the free opening.
- Set the filled oil gun (21).
- Using the oil gun (21), inject the hydraulic oil (e.g. DEA Astron HLP 32 or a similar grade oil) firmly.
- Withdraw the oil gun (21) and unscrew the oil refill adapter screw (22).
- Screw on the socket head screw (7) with O-ring (8) and tighten using an internal hex key SW4 (23) (see page 25 "Table for torque values").
- Rub the riveting tool dry.
- Insert the nose piece (2).
- Loosen the fixed riveting tool.
- Reconnect the compressed air supply.
- Carry out a test run without blind rivet.





## Maintaining the riveting tool



**Caution** Hazard of injury if handled in an improper manner! Servicing, maintenance and repairs of the riveting tools must be carried out professionally. On completing this work, there should not be any more hazard to the operator, if used as per the regulations. The operator may only carry out the operations mentioned here.

### Bleeding the hydraulic section, refilling hydraulic oil

It is necessary to bleed the hydraulic system or to refill the hydraulic oil when:

- oil is leaking from defective O-rings,
- after an oil-change at the time of an overhaul (either after a maximum of 3 years, or after 2000 working hours).

- Detach the compressed air connection.



**Caution** Hazard of injury by means of bruises or cuts in case of unchecked cutting stroke! Always detach compressed air supply before take off the nose cap (2).





**Note** Take off nose cap (2), so that there is no more pressure on the hydraulic cylinder, else it would not be possible to fill in adequate oil.

- Unscrew the knurled nut (12) up to the end stop.



**Note** If you clamp the riveting tool into a vice, then insert a soft material in-between (Alu/ wood).



## Operating the riveting tool



**Caution** Hazard of injury due to the rivet head coming off! Therefore, examine the riveting tool without blind rivet. Wear safety glasses.




- Connect the compressed air supply (6 bar) onto the riveting tool.
- Check riveting tools before commencement of work by using the push-button (13). You can hear that a stroke is being initiated.
- Re-adjust knurled nut (12). Air must escape from the air outlet hole (6.1).



**Caution** Hazard of injury due to unchecked wearing out of the mandrel! Use only an undamaged spent mandrel collector, and ensure that it has been correctly fitted (always completely unscrew the spent mandrel collector).



**Attention** Material damage! Always work with artificial spent mandrel collector (6)! In the absence of the spent mandrel collector, the safety mechanism (4) closes the outlet. Collected mandrels are left back in the riveting tool, where they could jam. If proper attention is not paid, then the riveting tool may break down.



**Setting the blind rivet**

**What you must take care of**



**Attention** Material damage! Always set the riveting tool at the correct angle (90°) with the surface of the work-piece to be riveted. A slanted setting will lead to defective riveting.





**Note** The size of the opening (d1) and the grip range (K) for processed rivet you can find in data sheet of rivet producer.

- Connect compressed air (6 bar).
- Twist the knurled nut (12) until you can hear the air escape from the air outlet hole.
- Feed the blind rivet (a) into the nose piece (1). The blind rivet is sucked and held in the nose piece. Blind rivet must tightly fit the nose piece.



**Note** You must adjust the knurled nut (12) so far that the mandrel will be sucked off in the collector (6) after riveting.

- Straighten the trigger (13) upto the stop point and hold it there. The rivet body is upset and the blind rivet is thus set.
- Release trigger (13). After releasing the trigger, the spent mandrel is automatically sucked into the spent mandrel collector (6).



**Note** Clean the replaced nose piece (1) and screw into the collecting hole on the underside of the riveting tool using the box wrench SW11 (24)



**Attention** Material damage due to damaged threads. It should be possible to screw on the nose piece with bare hands. Do not use force! You must overcome the spring thrust on the jaws!

- Screw the nose piece (1) carefully into the nose cap (2).
- Tighten the nose piece (1) using the box wrench SW11 (24) (see page 25 "Table for torque values").

